

Lowering suspension systems

WAV WITH LOWERING SUSPENSION



Ford Transit





www.amf-bruns.de



ACCESSIBLE VEHICLE WITH LOWERING SUSPENSION

Ford Transit









The lowered vehicle can be accessed by the wheelchair.

Vehicle with folded ramp. Rear view is maintained

Vehicle ready for departure (standard height).

Lowered vehicle.



Tomorrow's safety today!

FUTURESAFE®

Head- & backrest

FutureSafe is a safe, spacesaving and comfortable patented safety system, which is flexibly customisa-ble and comes with an integrated shoulder belt for the wheelchair occupant.

PROTEKTOR®

Wheelchair & occupant restraint system

AMF-Bruns Protektor restraint system meets DIN 75078 part II, ISO 10542.

PROSAFE®

"Kraftknotenadapter" Integrated lap belt

With the "Kraftknotenadapter" system the wheelchair is quickly and precisely fitted to the vehicle's floor. It comes with a pelvic belt for the wheelchair occupant.

TECHNICAL DATA

» Lowering system

Strong, low-noise power pack, 12 V

» Power

Electro-hydraulic from battery

Aluminium with anti-slip surface, » Ramp foldable in the centre, gas strut

supported, profile: Euro Ramp

» Lowering operation

Via rocker switch in the rear

» Lifting operation

Automatically when rear door

is being closed

» Wheelchair restraint

4-point wheelchair restraint system,

crash tested

» Safety belt for the wheelchair occupant

Pelvis belt and automatic shoulder belt, slip-on wheelchair head rest

AMF-BRUNS PROVIDES THE MAXIMUM OF SAFETY

- » EMC testing according to EU regulations
- » Security valves ensure smooth lowering and lifting of the vehicle.
- » The AMF-Bruns 4-point restraint system meets DIN 75078, and ensures that the wheelchairs are safely fixed to the vehicle's floor.
- » The height-adjustable AMF-Bruns automatic shoulder belt is in-vehicle tested according to DIN 75078, 76/115 EWG, and ISO 10542.
- » All mounting parts 20 G pull-tested.



AMF-Bruns GmbH & Co. KG | Hauptstraße 101 | 26689 Apen Telefon +49 (0) 44 89 / 72 72 50 | Fax +49 (0) 44 89 / 62 45 hubmatik@amf-bruns.de

