

Lift systems

PremiumPartner

von Volkswagen Nutzfahrzeuge

AMF-BRUNS CASSETTE LIFT K90

Volkswagen Multivan/Caravelle/Transporter T6





www.amf-bruns.de



AMF-BRUNS CASSETTE LIFT K90 FOR VW T6

Slim AMF-Bruns cassette lift for the side loading door





K90 in lowest position at the ground. Barrier folded down.

THESE FACTS MAKE ALL THE DIFFERENCE

- » Load capacity 300 kg
- » Slim design guarantees ultimate ground clearance
- » New illuminated controls, waterproof and shockproof (!)
- » Automatic barrier operates on uneven roads and snow, too!
- » Original step is obtained

- » Powerful, quiet action ensures smooth operation of the lifting platform
- » Totally enclosed stainless steel box provides protection for the lift system even in extreme weather conditions
- » Large lifting platform, suitable for large electric wheelchairs
- » Vehicle interior remains unchanged

- » No changes to the car body necessary
- » Manual emergency operation
- » EMC tested according to EU regulations
- » Meets EN 17576, Il requirements

TECHNICAL DATA

» SWL 300 kg » Control By push buttons

Approx. 800 x 1.200 mm » Platform size Lifting and lowering electro-hydraulic 12 V; » Power

deploying and stowing driven by 12 V

» Unladen weight Approx. 165 kg electric motor

» Lifting Approx. 6 sec » Optional Bluetooth remote control or app

operation (iOS, Android) » Lowering Approx. 8 sec

AMF-BRUNS PROVIDES THE MAXIMUM OF SAFETY

- » Safety barrier ensures feet cannot be trapped in mechanism when lifting platform
- » Fully automatic roll-off stop
- » Two warning lights flash automatically when platform is deployed, and give warnings in poor visibility
- » Safety switches ensure lift cannot be operated when door is closed



AMF-Bruns GmbH & Co. KG | Hauptstraße 101 | D-26689 Apen Telefon +49 (0) 44 89 / 72 72 50 I Fax +49 (0) 44 89 / 62 45 hubmatik@amf-bruns.de

