

Lowering suspension systems

WAV WITH LOWERING SUSPENSION



Opel Movano







ACCESSIBLE VEHICLES WITH LOWERING SUSPENSION

Opel Movano



The lowered vehicle can be accessed by the wheelchair.



Vehicle with folded ramp. Rear view is maintained.



Vehicle ready for departure (standard height).



Lowered vehicle.



Tomorrow's safety today!

FUTURESAFE®

Head & backrest

FutureSafe is a safe, spacesaving and comfortable patented safety system, which is flexibly customisable and comes with an integrated shoulder belt for the wheelchair occupant.

PROTEKTOR®

Wheelchair & occupant restraint system

AMF-Bruns Protektor restraint system meets DIN 75078 part II, ISO 10542.

PROSAFE®

"Kraftknotenadapter" Integrated lap belt

With the "Kraftknotenadapter" system the wheelchair is quickly and precisely fitted to the vehicle's floor. It comes with a pelvis belt for the wheelchair occupant.

TECHNICAL DATA

» Lowering system Strong, low-noise power pack, 12 V

» Power Electro-hydraulic from battery

» Ramp Aluminium with anti-slip surface, foldable in the centre, gas strut

supported, profile: Euro Ramp

» Lowering operation Via rocker switch in the rear » Lifting operation Automatically when rear door

is being closed

» Wheel chair restraint 4-point wheelchair restraint system,

crash tested

» Safety belt for the Pelvis belt and automatic shoulder wheelchair occupant

belt, slip-on wheelchair head rest

AMF-BRUNS PROVIDES THE MAXIMUM OF SAFETY

- » EMC testing according to EU regulations
- » Security valves ensure smooth lowering and lifting of the vehicle
- » The AMF-Bruns 4-point restraint system meets DIN 75078, and ensures that the wheelchairs are safely fixed to the vehicle's floor
- » AMF-Bruns automatic shoulder belt is height-adjustable and in-vehicle tested according to DIN 75078 and EU regulation 2007/46
- » All mounting parts 20 G pull-tested



AMF-Bruns GmbH & Co. KG | Hauptstraße 101 | D-26689 Apen Telefon +49 (0) 44 89 / 72 72 50 | Fax +49 (0) 44 89 / 62 45 hubmatik@amf-bruns.de

